

Experiment No.:- 05.

1. > Aim:-> To determine the wavelength of Sodium Light by Newton's Ring

2. > Apparatus:-> Monochromatic Light, Mount

(At the bottom of which we place plane glass and lens, Light is directed to the lens by the reflector fixed on the top of it)

Optical flat glass plate, Plano Convex lens


Travelling Microscope.

3. > Theory:->


Newton's Ring:-> The phenomenon of Newton's Ring is named after the scientist Sir Isaac.

Newton's is an interference pattern caused by the reflection of light between two surfaces

[Signature]
Teacher's Signature



1) Schematic diagram of light rays in Newton's Ring.



II) Newton's Ring.

Sydney

→ A spherical surface

→ An adjacent flat surface

When the beam of monochromatic light is incident normally (shown here as A) on a combination of plano-convex lens and a glass plate, a part of each incident ray is reflected from the lower surface of the lens (shown here as E) and a part after refraction (BC) through the air film between the lens and the plate is reflected back from the plane surface (shown here as A).

These two refracted rays, are coherent and as the lens is symmetric along its axis as well as the thickness is constant along the

circumference of a ring of a given radius, hence will interfere and produce a system of alternate dark and bright circular rings.

4) Formula used:->

The main scale has 20 divisions between 2cms and Vernier scale has 50 divisions.

Least count of the microscope:->

$$\left(\frac{1}{2}\right) \times 50 = 0.001 \text{ cm}$$

Take the reading of main scale (MSR) by reading just before zero of vernier scale.

For vernier scale reading, only one line of vernier scale coincide with the main scale (MSR)

So, the total reading will be :->

$$\Rightarrow \underline{MSR + (CCSR \times LC)} = TSR$$

⇒ Plot the graph between $(\text{Diameter})^2$ and No of rings.

Find out the slope of the graph between m^{th} and n^{th} rings and use the following formula to evaluate the wavelength (λ) of sodium lamp.

$$\lambda = \frac{D_m^2 - D_n^2}{m - n} \times \frac{1}{4R}$$

where,

$\frac{D_m^2 - D_n^2}{m - n}$ is the slope of the graph.

⇒ R is the radius of curvature of the plano convex lens.

Least count of Microscope.

Main scale has 20 divisions between 2cms and Vernier scale has 50 divisions


$$\Rightarrow \left(\frac{1}{2} \div 50 \right) = \underline{\underline{0.001 \text{ cms}}}$$

Observation Table:->

S. No.	Ring No.	LHS			RHS			Diameter (D) D = b - a.	D ²
		Total = MSR + (LC x VSR)	MSR	VSR	Total = MSR + (LC x VSR)	MSR	VSR		
				TSR (a)			TSR (b)		
1	20	2.24	29	2.269	2.7	27	2.727	0.458	0.209764
2	16	2.283	3	2.283	2.68	19	2.699	0.40620	0.165
3	12	2.28	20	2.30	2.64	6	2.646	0.34640	0.12
4	8	2.30	4	2.304	2.58	5	2.585 2.579	0.27568	0.076
5	4	2.30	45	2.345	2.5	16	2.516	0.171	0.0292

4.4
[Signature]

Diameter² vs No of Rings



Calculations \rightarrow

where,

$$\lambda_i = \frac{D_m^2 - D_n^2}{m - n} \times \left(\frac{1}{4R} \right)$$

$$R = \underline{\underline{50 \text{ cm}}}$$

$$\lambda_1 = \left(\frac{0.209764 - 0.165}{20 - 16} \right) \times \frac{1}{4 \times 50} = 5595.5 \text{ \AA}$$

$$\lambda_2 = \left(\frac{0.165 - 0.12}{16 - 12} \right) \times \frac{1}{4 \times 50} = 5625 \text{ \AA}$$

$$\lambda_3 = \left(\frac{0.076 - 0.02924}{8 - 4} \right) \times \frac{1}{200} = 5844.8 \text{ \AA}$$

$$\lambda_4 = \left(\frac{0.12 - 0.076}{12 - 8} \right) \times \frac{1}{200} = 5500 \text{ \AA}$$

$$\lambda_{\text{mean}} = \left(\frac{5595.5 + 5625 + 5844.8 + 5500}{4} \right)$$

$$\lambda_{\text{mean}} = \left(\frac{22565.3}{4} \right) = \underline{\underline{5641.325 \text{ \AA}}}$$

Result \rightarrow The wavelength of sodium light by Newton's Ring comes out to be 5641.325 \text{ \AA}

Signature

5) Result:-> The wavelength of sodium light by Newton's Ring comes out to be 5641.325 \AA Ans.

6) Percentage Error.

$$\Rightarrow \text{Percentage Error} = \left[\frac{\lambda_r - \lambda_s}{\lambda_s} \right] \times 100\%$$

where,

λ_r = Experimental wavelength = 5641.325 \AA

λ_s = Standard Wavelength = 5890 \AA

$$\begin{aligned} \% \text{ error} &= \left| \frac{5641.325 - 5890}{5890} \right| \times 100 \\ &= \underline{\underline{4.22\%}} \end{aligned}$$

7) Precautions and Sources of Error.

→ Glass Plate and Lens must be cleaned thoroughly

→ The Lens used should be of large radius of

Teacher's Signature:

[Signature]

curvature

- The source of light should be an extended one.
- Before measuring the diameter of rings, the range of microscope should be adjusted properly.
- Crosswire should be focussed on a bright ring tangentially.

biohaz